

FIG. 1

.**.**..




FIG. 2






FIG. 3

-+



CONFIGURATION MESSAGE

<u>600</u>




TOPOLOGY CHANGE NOTIFICATION MESSAGE

FIG. 6

+

<u>700</u>



PORT STATE TABLE PRIOR ART

FIG. 7

÷




FIG. 8

 \perp


9,000

•	910 }	912	913
	STATE	ROLE	UPLINKGUARD ENABLED
914~	FWD	ROOT PORT	DON'T CARE
916~	FWD	DESIGNATED PORT	NO
918	BLK	BLOCKED PORT	DON'T CARE
920~	BLK	UPLINK GUARD ENABLED BACKUP FOR ROOT PORT	DON'T CARE
922~	UPLINKGUARD INCONSISTENT = BLK	DESIGNATED	YES

PORT STATE TABLE

FIG. 9

+



10,008M

10,008P

M

10,008

10,008A

FIG. 10
